


# Roteador TP-LINK

## Guia Rápido de Configuração para troca de senha do roteador


### 1º Passo:

Acesse o roteador pelo seu navegador (Chrome/IE /Firefox) digitando umas dessas URL's.




### 2º Passo:

Digite o usuário e senha. Por padrão o roteador vem configurado com usuário: **admin** e senha: **admin**.




### 3º Passo:

Para configurar sua rede sem fio é simples, acesse o menu WIRELESS > CONFIGURAÇÕES e coloque o nome desejado da sua rede WIFI no campo destacado abaixo.




### 4º Passo:

Agora iremos configurar a senha para a rede criada no passo anterior. Acesse WIRELESS > SEGURANÇA WIRELESS. Digite sua senha no campo destacado abaixo e clique em salvar.



## 5º Passo:

Para terminar e as configurações começarem a valer, vamos reiniciar o roteador em FERRAMENTAS DO SISTEMA > REINICIAR.



The screenshot displays the router's web management interface. On the left, a vertical menu lists various configuration categories. The 'Ferramentas de Sistema' (System Tools) section is expanded, and the 'Reiniciar' (Restart) option is highlighted with a red box. The main content area features a green header with the word 'Reiniciar'. Below this, there is a sub-header 'Reiniciar' and a button labeled 'Reiniciar' with a red border. Underneath the button, the text reads: 'Clique neste botão para reiniciar o dispositivo.'